


Fensterheber ECU – FMS_PCB-Kontext (funktionale Zuordnung)



Legende

sw	hw
sw	hw
sw	hw
sw	hw

- [1] UserSignCtrl
- [2] WindowCtrl
- [3] AntiPinchCtrl
- [4] DiagCtrl

NA	hw
sw	hw
sw	hw

- [5] BatCtrl
- [6] CANComCtrl
- [7] LINComCtrl

- Kontext des FMS_PCB-Systems
- Systemelemente vom FMS_PCB